

### QUICK SET UP GUIDE

### PARADOX SP5500 ALARM SYSTEMS

#### Step 1: Intial Setup

1. Locate the Alarm panel (this will be located in a cupboard/WIR).
2. Open the panel and connect the battery, there will be a black and red lead loose, connect the black cable to black port on battery and red cable to red port.
3. Remove any booklets left in the panel and close door.
4. Turn on the power point beside the alarm panel and proceed to the Keypad at the entry of the home.
5. On the keypad the TBL button should now be illuminated RED.

#### Step 2: Setting the Date & Time

1. Press the **TBL** button (it will start to flash and the number 8 button will illuminate)
2. Press the number **8** button. (ARM & TBL will flash in unison)
3. Enter the time as **HH:MM**.
4. Press **1** for 24-hour clock (SLEEP & TBL will flash in unison)
5. Enter the year as **YYYY** (Stay & TBL will flash in unison)
6. Enter the month as **MM** (OFF & TBL will flash in unison)
7. Enter the day as **DD** (All indicators will stop flashing except the TBL button)
8. Press the **CLEAR** button to exit (TBL will stop flashing)

#### Step 3: Changing the Master Pin Code

1. Press the **PWR +1234** (PWR & 1 will flash in unison)
2. Press **01** (ARM will flash)
3. Enter your new 4 digit PIN (SLEEP will flash)
4. Re-Enter 4 digit PIN (STAY will flash)
5. Press the **ENTER** button (PWR and 2 will flash in unison)
6. Press the **CLEAR** button to exit.

#### Step 4: Arming & Disarming of your system

1. Leaving the house – Enter your 4 digit PIN Code to arm alarm.
2. When you return home – Enter your 4 digit PIN code to disarm alarm.



### \*\*\*\*\*MONITORING\*\*\*\*\*

We offer 24/7 back to base monitoring; if you are interested in having your home monitored, call our office where we can offer you a very competitive rate.

## FAULT FINDING

In the event of a trouble appearing on your keypad, Press the **[TBL]** button on your Keypad to view the trouble. Refer to the list below.

**PWR Flashing** – this error means that you need to replace the battery located in the alarm panel box.

1. **Wireless Zone** – Low Battery (need to replace the battery on the wireless sensor)
2. **Power Trouble** (check that the power supply beside alarm panel is plugged in. This error will also arise when power is lost at the premises, but will clear upon restoral of power)
3. **Bell Trouble**
4. **Communication Trouble** (if home is monitored, call your monitoring provider to ensure communication has been restored)
5. **Tamper & Zone Wiring Failure**
6. **Module Tamper Trouble**
7. **Fire Loop Trouble**
8. **Timer Loss**  
(follow step 2 on front page to reset time and date )
9. **Wireless Zone Supervisor Failure**
10. **Module Supervision loss**
16. **Keypad Fault**
17. **Upgrade panel to V3.2 or higher**

**SLEEP. Keypad Fault**

